



# Quick installation guide

## Deskstar 120GXP

Ultra ATA/100 Hard disk drive



Models: IC35L020AVVA07  
IC35L040AVVA07  
IC35L060AVVA07  
IC35L080AVVA07  
IC35L100AVVA07  
IC35L120AVVA07

---

### System requirements for Ultra ATA/100

---

If you do not have the components listed below, your drive will function but at speeds lower than 100 MB/s.

- 40-pin, 80-conductor cable
- A controller card or motherboard chipset with Ultra ATA/100 capability
- Ultra ATA/100 compatible BIOS or driver

---

### Handling precautions

---

- Set the drive down gently to prevent damage from impact or vibration.
- Do not open the ESD bag containing the drive until needed.
- Handle the drive carefully by the edges. Do not touch the exposed printed circuit board or any electronic components.
- Do not press on the top or bottom of the drive.
- Do not cover the drive breather hole.
- Before handling the drive, discharge any static electricity from yourself and your clothing. With one hand touch an unpainted metal surface on your computer chassis, then touch the ESD bag with the other hand. Remain in contact with the chassis and the bag for a minimum of two seconds.


---

### Quick installation procedure

---

Note: Back up all data before installing drive!

1. Turn off the computer.
2. Remove the computer cover as instructed by the computer system manual.
3. Discharge static electricity (see Handling precautions).
4. Unplug the computer.
5. Note the mounting position of existing drives and cables. If you are replacing a drive or any cable, remove it now.
6. Remove the drive from the ESD bag.
7. Record the model, the part number, and the serial number of the drive for future reference.
8. Insert the required jumpers. Refer to the jumper block diagram below.
  - If the drive is the only drive on a cable or the master drive on a two-drive cable, leave the jumpers as set at A-B and G-H for 16 head logical architecture. The jumpers are factory-set to Master-16 heads.
  - If the drive is the slave drive on a two-drive cable, set the jumpers at A-B and C-D for 16-head logical architecture.



9. Attach the IDE cable.
  - If you have a 40-pin 40-conductor cable, attach the system connector of the cable to the IDE port on the motherboard or controller card. The pin 1 side of the IDE cable is marked with a stripe. The connector can only be inserted one way.
  - If you have a 40-pin 80-conductor cable, attach the drive to the appropriate color-coded connector. Forty-pin 80-conductor cables are color-coded black for Master, gray for Slave, and blue for system connectors.
10. Attach the power supply cable to the drive. Match the connector bevels.
11. Mount the drive securely.
12. Verify all attachments.
13. Replace the computer cover.
14. Plug in the computer.
15. Power on your system, Insert your operating system setup disc or diskette and reboot your system.
16. Verify that the hard disk is recognized by the BIOS and is reporting the full capacity of the drive. Instructions for accessing your BIOS can be found in the computer system manual or in the motherboard manufacturer documentation. If the drive is not recognized in the BIOS, set the BIOS options of your computer system to Auto Detection and LBA mode if available. Once the drive is recognized correctly in the BIOS, it is ready to be partitioned and formatted.
17. Your operating system setup utility will provide instructions on how to partition and format your drive before it installs the operating system. For additional information, see:  
  

[www.ibm.com/harddrive](http://www.ibm.com/harddrive)
18. Once the operating system is installed, reboot the system. If the system does not boot up, check all the settings and try again. If the system still fails to boot up, call the IBM Support Center for assistance.



© International Business Machines Corporation 2001

[www.ibm.com/harddrive](http://www.ibm.com/harddrive)

**IBM Technology Group Support Center**

Telephone: 888.426.5214 or 507.286.5825

E-mail: [drive@us.ibm.com](mailto:drive@us.ibm.com)

**Singapore Technical Group Support Center**

Telephone: (65)6418.9595 or 1800.418.9595

E-mail: [drive@sg.ibm.com](mailto:drive@sg.ibm.com)

**UK Technical Group Support Center**

Telephone: 44.1475.898.125

E-mail: [drive@uk.ibm.com](mailto:drive@uk.ibm.com)

**Germany Technical Group Support Center**

Telephone: 49.7032.153050

E-mail: [drive@de.ibm.com](mailto:drive@de.ibm.com)

**IBM Systems Storage Division**

5600 Cottle Road

San Jose CA 95193

[www.ibm.com/storage](http://www.ibm.com/storage)

Printed in the United States of America

11-2001

All Rights Reserved

IBM is the registered trademark and Deskstar is the trademark of International Business Machines Corporation.

AMP is a trademark of AMP Incorporated.

Other company, product, and service names may be trademarks or service marks of others.

Produced by the IBM Technology Group Support Center.

Deskstar 120GXP Hark disk drive specifications, Revision 1.0

Product Description data represents IBM's design objectives and is provided for comparative purposes; actual results may vary based on a variety of factors. This product data does not constitute a warranty. Questions regarding IBM warranty terms or methodology used to derive this data should be referred to the IBM Technology Group Support Center.

Data is subject to change without notice.

References in this publication to IBM products, programs, or services do not imply that IBM intends to make them available in all countries in which IBM operates.